



Date: January 24, 2005
Order No.: P-B-80.57/29a
Supersedes:
Group: 80

Revision: Model and Technical Update
SUBJECT: MODEL 171.456/473
MODEL 203.040/061/064/065/076/081/084/261/264/281/284/740/747/764
MODEL 209.365/375/376/465/475/476
MODEL 211.026/065/070/076/082/083/265/282/283
MODEL 219.375
EXCHANGE AND DIAGNOSIS OF DAS3 COMPONENTS
(ALSO REFERED TO AS SI80.57-P-0001C)

i **Note:** The Star Diagnosis System (SDS) refers to this document as SI80.57-P-0001C.

As of the following Star Diagnosis System (SDS) versions below, troubleshooting for existing conditions with Drive Authorization or Access Authorization has been revised:

- Model 203 as of version 04/02
- Model 209 as of version 06/03
- Model 211 as of version 06/03
- Model 171 as of start of production
- Model 219 as of start of production

When troubleshooting in the Star Diagnosis System (SDS) DAS3 components, please proceed as follows:

For testing the Transmitter Key:


Select "Control Units" > "Body" > "EIS" > "Guided Test Of Transmitter Key."

For testing the Vehicle DAS system:

Select "Control Units" > "Body" > "EIS" > "Guided Test Of Drive Authorization System."

This bulletin has been created and maintained in accordance with MBUSA-SLP S423QH001, Document and Data Control, and MBUSA-SLP S424HH001, Control of Records.

Select the applicable condition here. For conditions with opening/closing of the vehicle, select "Guided Test Of Transmitter Key." For conditions with starting the vehicle, select "Guided Test Of Drive Authorization System." Guided diagnosis is then provided that will allow a clear determination of the malfunctioning component.

 **Note:** Both vehicle keys are required to ensure a proper diagnosis. Please be sure that both keys will be available when the repair appointment is made.